Surface linear

INSTALLATION GUIDE

990.0446.01 - 27/02/2025

Important



The light source in this product shall only be replaced by the original manufacturer, service agent or a similarly qualified person.



Control gear replaceable by a professional

For light source energy class, please refer to relevant product technical data sheet for further information.

Ingress protection:	Ceiling mounted	IP44
	Wall mounted	IP40
	Suspended	IP40

Please retain this guide for future reference and recycle packaging.



We reserve the right to amend any product specification without prior notice. Any alterations made to the luminaire may affect life and light output and invalidate any warranty. Luminaire complies with all safety standards set out in BS EN 60598.

1

Isolate mains supply before commencing installation

- Using a suitable flat-bladed screwdriver, carefully prise out 2 x diffuser retainer pins from end-cap and store for reuse.


2

- Slide diffuser towards open pin-holes (1).
- Push edges of diffuser inwards (2) and release from body

4


- Connect mains supply to terminal block.
- For switch dim, link D2 to N and connect D1 to mains supply via a push to make retractive switch.

STANDARD



N - NEUTRAL
⏚ - EARTH
L - LIVE (switched) (permanent for switch DIM)

EMERGENCY



N - NEUTRAL
⏚ - EARTH
1 - SWITCHED LIVE
2 - PERMANENT LIVE

DIMMING / DALI EM



D1 - DALI +
D2 - DALI -

5

6

Reinstate mains supply