INSTALLATION GUIDE:

EXTRUDED DIRECT / INDIRECT LINEAR SUSPENDED 990.0366.01

IMPORTANT:

This product contains a light source of energy class C. Refer to product technical datasheet for further information.

The light source contained in this luminaire shall only be replaced by the manufacturer, their service agent or a similarly qualified person.

The luminaire has an ingress protection rating of IP20.

Ensure the mounting surface is capable of supporting the weight of the luminaire before commencing installation.















Please retain this guide for future reference and recycle packaging.




- Prise out the downlight diffuser using a plastic lever tool (not supplied) or card, starting in the centre of the diffuser and working outwards.
 - Please note: Do not use metal tools such as screwdrivers to do this as they may damage the diffuser / body






- Slide tray to one end and remove



Disconnect the driver connectors and the earth spade to release the downlight LED trav.




IMPORTANT: Electrical termination must be carried out by a qualified electrician in accordance with the latest edition of IEE wiring regulations BS7671.

- Remove uplight diffuser end pieces.
- Thread suspension cables into suspension clutches whilst raising luminaire to desired heiaht.
- Make sure luminaire is level.
- Trim excess suspension cable.
- Feed the mains cable through the cable gland and secure

- Connect mains supply to terminal block.
- For switch dim, link D2 to N and connect D1 to mains supply via a push to make retractive switch.



- N NEUTRAL
- ♣ EARTH
- L LIVE (switched)



- N NEUTRAL
- ♣ EARTH 1 - SWITCHED LIVE
- 2 PERMANENT LIVE


DIMMING



- L2 PERMANENT LIVE*
- D1 DALI +
- D2 DALI -

G

- Offer up the LED tray and reconnect the driver connectors and the earth spade.
- Push the LED tray up into the body ensuring the clips are correctly aligned and secure and no wires are trapped.
- Push the diffusers back into the luminaire until secure.





REINSTATE MAINS SUPPLY

We reserve the right to amend any product specification without prior notice. Any alterations made to the luminaire may affect life and light output and invalidate any warranty. Luminaire complies with all safety standards set out in BS EN 60598. REV 1 29/11/2022

INSTALLATION GUIDE:

IMPORTANT: Electrical termination must be carried out by a qualified electrician in accordance with the latest edition of IEE wiring regulations BS7671.

SUSPENDED DIRECT / INDIRECT LINEAR - JOINING KITS

990.0375.01



7 K

PLEASE RETAIN THIS GUIDE FOR FUTURE REFERENCE AND RECYCLE PACKAGING. PERFORM INSTALLATION BEFORE CLIPPING GEAR TRAYS AND DIFFUSERS BACK INTO LUMINAIRE 00 90° JOINT PERFORM INSTALLATION BEFORE CLIPPING GEAR TRAYS AND DIFFUSERS BACK INTO LUMINAIRE 00 IN-LINE JOINT

We reserve the right to amend any product specification without prior notice. Any alterations made to the luminaire may affect life and light output and invalidate any warranty. Luminaire complies with all safety standards set out in BS EN 60998.