

INSTALLATION GUIDE:

LED BULKHEAD
990.0392.01










IMPORTANT:

This product contains a light source of energy class E, refer to relevant product technical data sheet for further information.

The LED module in this luminaire is not replaceable. When the light source reaches its end of life, the whole luminaire must be replaced.

The luminaire has an ingress protection rating of IP54 from the room side once installed.

PLEASE RETAIN THIS GUIDE FOR FUTURE REFERENCE AND RECYCLE PACKAGING

<p>A  ISOLATE MAINS SUPPLY BEFORE COMMENCING INSTALLATION</p> <ul style="list-style-type: none">- Mark and drill mounting points. Ensure suitable fixings are used (not supplied). 	<p>B</p> <ul style="list-style-type: none">- Remove mounting bracket from luminaire and fix to mounting surface. 
<p>C</p> <ul style="list-style-type: none">- Select colour temperature (where available) 3000 K = WW 4000 K = DW / NW 5500 K = DL / CW 	<p>D IMPORTANT</p> <p>Electrical termination must be carried out by a qualified electrician in accordance with the latest edition of IEE wiring regulations BS7671</p> <ul style="list-style-type: none">- Remove terminal cover & connect mains supply- Secure cable using clamp & re-fit cover. 
<p>E</p>  <ul style="list-style-type: none">- Attach luminaire body to mounting bracket and secure with 2 fixing screws. <p style="text-align: right;"> REINSTATE MAINS SUPPLY</p>	