

# INSTALLATION GUIDE:

INDUSTRIAL LED LINEAR  
990.0361.01



## IMPORTANT:

The luminaire must not be covered by any debris or insulating material. Ensure there is a minimum of 50 mm airspace around the luminaire. Electrical termination must be carried out by a qualified electrician in accordance with the latest edition of IEE wiring regulations BS7671.

**PLEASE RETAIN THIS GUIDE FOR FUTURE REFERENCE AND RECYCLE PACKAGING.**

### A ISOLATE MAINS SUPPLY BEFORE COMMENCING INSTALLATION

### ENSURE MOUNTING SURFACE IS CAPABLE OF SUPPORTING THE WEIGHT OF THE LUMINAIRE

- Remove 6x gear tray fixing screws to release the gear tray from the luminaire housing, allowing it to hang from the tethers.

### B<sub>1</sub> SURFACE OR BESA MOUNTING

### B<sub>2</sub> SUSPENDED MOUNTING

- Measure and mark the positions of the fixing holes as shown.
- Fit the luminaire using suitable screws (not supplied)

- Measure and mark the required mounting positions as and fit the ceiling fixings as shown.
- Fit the two fixing pillars and the cable gland into the luminaire body for mains cable entry.

### C

### D

- Thread suspension cables into suspension clutches whilst raising luminaire to desired height.
- Make sure luminaire is level.
- Trim excess suspension cable.

**STANDARD**

N - NEUTRAL  
 ⚡ - EARTH  
 L - LIVE (switched)

**EMERGENCY**

N - NEUTRAL  
 ⚡ - EARTH  
 1 - SWITCHED LIVE  
 2 - PERMANENT LIVE

- Connect the mains supply to the terminal block in the gear tray.
- Offer the luminaire up to the gear tray and reattach with the 6x fixing screws, ensuring no cables are trapped

**REINSTATE MAINS SUPPLY**

We reserve the right to amend any product specification without prior notice. Any alterations made to the luminaire may affect life and light output and invalidate any warranty. Luminaire complies with all safety standards set out in BS EN 60598.